

# COAX

## CONNECTORS LTD

1. Slide crimp sleeve onto cable
2. Strip cable. Ensure centre conductor is not damaged.



3. Fan the braid out
4. Slide the cable into the connector and push home. Check that the centre conductor has engaged and is being gripped by the Centre contact



5. Slide the crimp sleeve over the braid
6. Crimp the crimp sleeve using the appropriate sized crimp tool (trim excess braid if necessary)

